

Auxiliary Controls

Windscreen wipers/washers

- On right hand side of steering column
- Lift up for 3 speeds
- Pull towards you for rear wipers
- Press button for washers

Side/Head Lights

- Rotary switch on right hand side of dashboard
- Turn clockwise
- 1st position - side lights
- 2nd position – headlights
- Always drive on headlights
- Main beam
- Indicator arm - pull towards you
- Dashboard warning light

Fog Lights

- Rotary switch on right hand side of dashboard
- Only works when lights are on
- Pull out
- 1st position - front foglights
- 2nd position - hi intensity rear fog lights
- Dashboard warning light
- Visibility must be less than 100 M

Hazard lights

- Push switch in centre of dash board
- Operates all four indicators
- Only use in emergency, stopping on motorways
- Do not use for illegal parking

Windows

- Side windows
- 2 switches on drivers arm rest
- Up/down - both sides
- Front/Back windows
- Demist
- 2 switches in front of gear lever

Gauges

- Speedometer
- Rev Counter
- Temperature
- Fuel