

Hand Controls

Parking Brake

- Only use when Stationary
- Only operates on 2 wheels
- Doesn't activate brake lights
- Press in ratchet when applying
- Lift up and press in ratchet when releasing

Gear Lever

- Changes gear to match engine speed to road speed
- Neutral
 - Middle position
 - Moves sideways
 - No drive - safe
- Look ahead when changing gear
- Palming Method
 - 1st - Most Powerful
 - Moving off
 - Maneuvers
 - 2nd & 3rd - Working Gears
 - Traffic
 - Town
 - 4th & 5th - Cruising Gears

Steering Wheel

- Hold lightly
- 10 to 2 or 1/4 to 3
- Keep two hands on wheel
- Pull Push method
 - Don't cross hands
- Dry steering
 - When car is stationary
 - Avoid

Indicators

- On left hand side of steering column
- Moves same way as Steering wheel
- Orange lights front & back
- Shows other road users of intentions

Other Controls

- Explained later